



# **INSTRUCTION BOOKLET**

## **MODEL: 02074G01 1800W-B**



**For you safety and continued enjoyment of this product**

**Always read the instruction book carefully before using**

### **IMPORTANT SAFEGUARDS**

- **READ ALL INSTRUCTIONS**
- Use only on AC 220-240 Volt, 50/60 Hz. Use only for household.
- Do not touch hot surfaces. Use handles.
- To protect against risk of electric shock, do not immerse the cord, plug or cooking unit in water or any other liquid.
- Close supervision is necessary when any appliance is used by or near children.

- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning appliance.
- Do not operate any appliance with a damaged has malfunctioned or has been damaged in any manner. In order to avoid the risk of an electric shock, never try to repair the Press Grill yourself. Take it to an authorized service station for examination and repair. An incorrect reassembly could present a risk of electric shock when the Press Grill is used.
- The use of accessory attachments not recommended by the manufacturer may result in fire, electrical shock, or risk of injury to persons.
- Do not use outdoors or for commercial purposes.
- Do not let power cord hang over the edge of the table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner or heated oven.
- Unplug the unit when finished using.
- Do not intend to operate by means of an external timer or separate remote-control system.
- Extreme caution must be exercised when moving an appliance.

## PARTS IDENTIFICATION



1. Oil Tray
2. Ready Light (Red)
3. Upper Housing
4. Power Light
5. Ready Light
6. Face Plate
7. Bottom Housing

## BEFORE FIRST USE

- Read all instructions carefully and keep them for future reference.
  - Remove all packaging
  - Clean the Cooking Plates by wiping a sponge or cloth dampened in warm water.  
**DO NOT IMMERSE THE UNIT AND DO NOT RUN WATER DIRECTLY ONT THE COOKING SURFACES.**
  - Dry with a cloth or paper towel.
  - For best results, lightly coat the cooking plates with a little cooking oil or cooking spray.
- Notice: When your Grill Toaster is heated for the first time, it may emit slight smoke or odor. This is normal with many heating appliances. This does not affect the safety of your appliance.**

## HOW TO USE

- Close the Grill Toaster and plug it into the wall outlet, you will notice that the ready light will come on, indicating that the Grill Toaster has begun preheating.
  - It will take approximately 5 minutes to reach baking temperature, the ready light will go off.
  - Put the sandwich, meat or other foods on the bottom cooking plate.
  - The ready light will go on again.
- Cook for about 6 to 12 minutes, the ready light goes off again, or until golden brown, adjusting the time to suit your own individual taste.
- Remove the food with the help of a plastic spatula. Never use metal tongs or a knife as these can cause damage to the non-stick coating of the cook plates.
  - Once you are finished cooking, disconnect the plug from the wall outlet and leave unit open to cool.

## CLEANING AND CARE

- Always unplug the Grill Toaster and allow it to cool before cleaning. The unit is easier to clean when slightly warm. There is no need to disassemble Grill Toaster for cleaning. Never immerse the Grill Toaster in water or place in dishwasher.
  - Wipe cooking plates with a soft cloth to remove food residue. For baked on food residue squeeze some warm water mixed with detergent over the food residue then clean with a non-abrasive plastic scouring pad or place wet kitchen paper over the grill to moisten the food residue.
  - Do not use anything abrasive that can scratch or damage the non-stick coating.
  - Do not use metal utensils to remove your foods, they can damage the non-stick surface.
  - Wipe the outside of the grill toaster with a damp cloth only. Do not clean the outside with any abrasive scouring pad or steel wool, as this will damage the finish. Do not immerse in water or any other liquid.
  - Do not place in the dishwasher.
- Remove and empty the drip tray after each use and wash the tray in warm, soapy water. Avoid the use of scouring pads or harsh detergents as they may damage the surface.

Rinse and dry thoroughly with a clean, soft cloth and replace.

## STORAGE

- Always unplug the Grill Toaster before storage.
- Always make sure the Grill Toaster is cool and dry before storing.

## WARRANTY

2 Years